



## DISPLAY RACK ASSEMBLY INSTRUCTIONS



To attach stands

1. Insert the larger slot at the bottom first,
2. Then align the other two slots
3. Slide stand all the way thru the front panel and up.



Your display rack may require a small cardboard shim to reduce 'wobble'.

This shim should be inserted in the back between the stands and the front as shown below.



You can leave the display in its natural wood finish, or paint / stain as desired.